

STEP 1 (Note: iOS 4.0 or higher is required)

Scan the code at right with the OPN2002 to choose Bluetooth-HID (Keyboard) mode.



Use the following label to put your OPN2002 in iPhone mode. This makes it possible to toggle the on-screen keyboard while being connected.



STEP 2

Hold the Clear/Function key (see diagram above) on the OPN2002 for five seconds, until it beeps and the LED begins flashing blue.

STEP 3



Turn on Bluetooth on your iPhone. The iPhone will now automatically discover your OPN2002. Once discovered, select the OPN2002 on your iPhone.

Once chosen, the OPN2002's laser will light up and you will hear a steady beep. Use the number barcodes provided on the right to scan the displayed pin code, one number at a time. When you are done, scan 'END' to complete the pairing.



STEP 4

Your OPN2002 is now paired and connected. The LED blinks blue slowly to